

# CDN Resource Laboratories Ltd.

10945-B River Road, Delta, B.C., V4C 2R8, 604-540-2233, Fax: 604-540-2237

## GOLD ORE REFERENCE STANDARD: CDN-GS-30A

Recommended value and the "Between Laboratory" two standard deviations

**Gold concentration: 35.25 ± 1.21 g/t**

**PREPARED BY:** CDN Resource Laboratories Ltd.

**CERTIFIED BY:** Duncan Sanderson, B.Sc., Licensed Assayer of British Columbia

**INDEPENDENT GEOCHEMIST:** Dr. Barry Smee., Ph.D., P. Geo.

**DATE OF CERTIFICATION:** June 30, 2006

### **ORIGIN OF REFERENCE MATERIAL:**

Standard CDN-GS-30A was prepared using reject ore material supplied by the Hunter Dickinson Group from the Specogna deposit. The Specogna deposit is a low sulphidation epithermal gold deposit of Miocene age and is localized along the Sandspit fault. Gold bearing breccia, vein and stockwork development occurs along the fault and subsidiary dilational structures extending upward into a thick hanging wall sequence of clastic sediments. Mineralization at Specogna is dominated by pyrite and marcasite which typically comprise 1 to 4% of the host rocks. Gold and silver occur as electrum.

### **METHOD OF PREPARATION:**

Reject ore material was dried, crushed, pulverized and then passed through a 200 mesh screen. The +200 material was discarded. The -200 material was mixed for 5 days in a V-blender. Splits were taken and sent to 11 commercial laboratories for round robin assaying. Round robin results are displayed below:

	Lab 1	Lab 2	Lab 3	Lab 4	Lab 5	Lab 6	Lab 7	Lab 8	Lab 9	Lab 10	Lab 11
	Au g/t	Au g/t	Au g/t	Au g/t	Au g/t	Au g/t	Au g/t	Au g/t	Au g/t	Au g/t	Au g/t
	34.20	35.30	34.97	35.3	35.25	36.0	34.80	35.1	36.9	35.79	35.01
	33.90	36.40	35.84	35.0	34.97	35.6	35.40	35.9	34.8	34.33	35.68
	35.17	35.25	35.71	34.5	34.83	35.8	35.20	36.4	36.3	36.05	35.04
	34.80	36.65	35.95	35.2	35.50	34.7	35.47	35.0	36.3	35.93	35.89
	34.00	35.25	34.64	33.9	35.07	35.0	35.80	36.1	35.1	35.20	35.26
	34.33	36.05	35.95	32.6	34.76	32.3	35.07	35.8	34.5	34.43	35.21
	34.77	35.30	35.02	35.7	34.69	35.2	35.40	34.9	34.4	35.37	35.76
	33.37	35.70	35.02	35.9	35.18	35.8	35.97	36.6	34.5	35.15	35.45
	34.07	35.60	34.71	34.8	35.53	34.7	35.60	35.3	36.5	35.02	35.10
	33.23	35.10	35.26	34.5	34.76	35.2	35.13	34.8	35.1	31.54	34.62
Mean	34.18	35.66	35.31	34.7	35.05	35.0	35.38	35.6	35.4	34.88	35.30
Std. Dev.	0.616	0.537	0.512	0.958	0.307	1.064	0.351	0.654	0.956	1.308	0.393
%RSD	1.80	1.51	1.45	2.76	0.88	3.04	0.99	1.84	2.70	3.75	1.11

**Assay Procedure:** all assays were fire assay, gravimetric finish on 30g samples

### APPROXIMATE CHEMICAL COMPOSITION:

	Percent		Percent
SiO <sub>2</sub>	63.2	Na <sub>2</sub> O	3.2
Al <sub>2</sub> O <sub>3</sub>	14.5	MgO	2.3
Fe <sub>2</sub> O <sub>3</sub>	7.4	K <sub>2</sub> O	1.2
CaO	5.2	TiO <sub>2</sub>	0.6
MnO	0.1	LOI	0.9

## GOLD ORE REFERENCE STANDARD: CDN-GS-30A

### **Statistical Procedures:**

The mean and standard deviation for all data was calculated. Outliers were defined as samples beyond the mean  $\pm$  2 Standard Deviations from all data. These outliers were removed from the data and a new mean and standard deviation was determined. This method is different from that used by Government agencies in that the actual "between-laboratory" standard deviation is used in the calculations. This produces upper and lower limits that reflect actual individual analyses rather than a grouped set of analyses. The limits can therefore be used to monitor accuracy from individual analyses, unlike the Certified Limits published on other standards.

### Participating Laboratories:


(not in same order as table of assays)

Acme Analytical Laboratories Ltd., Vancouver, Canada  
Activation Laboratories, Ontario, Canada  
ALS Chemex, North Vancouver, Canada  
Assayers Canada Ltd., Vancouver, Canada  
Ecotech Laboratory, Kamloops, Canada  
Genalysis Lab.Services, Australia  
International Plasma Laboratories Ltd., Richmond, Canada  
Omac Laboratory, Ireland  
SGS-XRAL, Ontario, Canada  
Teck Cominco, Global Discovery Laboratory, Vancouver, Canada  
TSL Laboratories Ltd., Saskatoon, Canada


### Legal Notice:

This certificate and the reference material described in it have been prepared with due care and attention. However CDN Resource Laboratories Ltd. nor Barry Smee accept any liability for any decisions or actions taken following the use of the reference material. Our liability is limited solely to the cost of the reference material.

Certified by

  
\_\_\_\_\_  
Duncan Sanderson, Certified Assayer of B.C.

Geochemist

  
\_\_\_\_\_  
Dr. Barry Smee, Ph.D., P. Geo.